west elm

Arc Mid-Century Sconce – Single Assembly Instructions

CAUTION:

• BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- We strongly recommend that a professional electrician install all direct wire fixtures.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A
 PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS
 INVOLVED.
- The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- This fixture has been rated for up to one (1) 60-watt maximum TYPE B standard (candelabra) incandescent light bulb (not included) or one (1) 13-watt compact fluorescent light bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- Use with approved West Elm Shade only, having a minimum opening diameter of 3-1/2 inches and a minimum lamp-to-shade spacing of 2-1/2 inches.
- The lighting fixture is meant for indoor use, SUITABLE FOR EITHER DRY OR DAMP LOCATIONS.
- Save these instructions.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.
- This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects
 and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light
 fixture.


Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended.

US/CN Page 1 of 5

Arc Mid-Century Sconce – Single Assembly Instructions

Tools Required: (not included):





Parts Included:

- (B) Green Ground Screw (1)
- (D) Canopy Screws (3)
- (E) Mounting Plate (1)
- (F) Canopy (1)
- (G) Socket (1)
- (H) Shade (1)

Hardware Enclosed:

- (A) Plastic Wire Nut Connectors (3)
- (C) Mounting Screws (3) (includes (1) extra)






US/CN Page 2 of 5


Arc Mid-Century Sconce – Single Assembly Instructions

Assembly Instructions:


- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- Carefully unpack all fixture parts and hardware and lay them on a clear workspace.



1. Separate the Mounting Plate (E) from the Canopy (F) by removing the 2 Canopy Screws (D). Do not discard the Canopy Screws (D) as these will be used later.




2. Insert the J-box wires through the center opening of Mounting Plate (E). Attach the Mounting Plate (E) to the outlet box using the 2 J-box Mounting Screws (C), Align the slots of the Mounting Plate (E) with the two threaded holes located on the J-box. Secure the Mounting Plate (E) by turning the 2 Mounting Screws (C) until tight




3. Please read the section" To Make the Wire Connections" Below.

US/CN Page 3 of 5


Arc Mid-Century Sconce - Single Assembly Instructions



4. Position the Canopy (F) over the Mounting Plate (E), aligning the 2 holes on the Canopy (F) with the 2 holes on the Mounting Plate (E). Secure the Canopy (F) by tightening 2 Canopy Screws (D)



5. Attach the Shade (H) over onto the Socket (G) until secure.




6. Insert the specified light bulbs into the Socket (G). DO NOT EXCEED THE SPECIFIED WATTAGE.

US/CN Page 4 of 5

Arc Mid-Century Sconce – Single Assembly Instructions

To Make the Wire Connections:

- 1. Gently pull existing wire down from the junction box and allow wires to hang. The HOT or LIVE wire is usually black. The NEUTRAL wire is usually white. Check to see if there is a ground wire that is usually green or green with a yellow stripe or exposed copper metal wire. If needed, use a pair of wire strippers to remove about 1/2 inch of insulation from each wire.
- 2. Carefully inspect the fixtures wires. The NEUTRAL FIXTURE WIRE is White. The HOT FIXTURE WIRE is Black. The BARE COPPER WIRE is the GROUND WIRE. If you have any doubt and cannot identify the power-supply wires with confidence, then we recommend that you ask an electrician and that you not continue with the installation.
- 3. With the help of another person to hold the weight of the fixture, attach the fixture wires to the junction box wires as shown in the illustrations.



Connect the GROUND FIXTURE WIRE to the GROUND J-BOX WIRE using the Plastic Wire Nut Connector (A) and wrap the connection with electrical tape. Be sure that no wire strands are exposed.

If the junction box DOES NOT have a GROUND WIRE, wrap the fixture's bare ground wire around the Green Ground Screw (B) and insert the screw into the Mounting Plate (E), marked as "GND", and tighten screw to secure the wire.

Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL J-BOX WIRE first and then connect the HOT FIXTURE WIRE to the HOT J-BOX WIRE using the Plastic Wire Nut Connectors (A). Wrap these connections with electrical tape. Be sure that no wire strands are exposed.

NOTE:

IT IS IMPERATIVE THAT THE JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED! DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

4. Check the wiring connections and if all looks good, gently tuck the wire connections neatly into the ceiling junction box.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

Thank you for your purchase Stores | catalog | <u>www.westelm.com</u> USA 888-922-4119

US/CN Page 5 of 5