POTTERY BARN

Somerville Alarm Clock

Operating Instructions

TO INSTALL BATTERY:
- Open the back of the clock.
- Insert a new 1.5 volt "AA" battery. (Battery not included.) Match the battery direction to the polarity markings displayed inside the compartment. Movement should start immediately. Should the clock fail to function properly or the alarm sound becomes "fuzzy", replace with a new battery and ensure that it is correctly positioned in the battery compartment.
- Replace back of clock.

TO SET TIME:
- The TIME SET dial is located inside the back of the clock.
- Turn the TIME SET dial in the direction indicated by the arrow until correct time is reached. Do not touch or move hands of clock manually.

TO SET ALARM TIME:
- Turn the ALARM SET dial in the direction indicated by the arrow until the alarm hand reflects the desired alarm time.
- To activate the alarm, the button at the top must be in the upright position.
- To turn off the alarm, press the button down.

CARE INSTRUCTIONS:
- Clean clock with a soft, dry cloth.
- Do not use solvents or abrasive cleaners on the clock as they may damage the lacquered finish.

BATTERY CARE:
- Batteries should be handled under adult supervision
- To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge standard or alkaline batteries.
- Please dispose of batteries safely according to the battery manufacturer's instructions or recycle battery per state and local codes.
- If battery leakage occurs and comes in contact with the skin or eyes, wash immediately with plenty of water.
- If the clock is not to be used for a long period of time, remove the battery to prevent damage or injury from possible battery leakage.