POTTERYBARN

QUINN BEADED TRIPLE SCONCE

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before installing forture.
- We strongly recommend that a professional electrician install all direct wired fixtures.
- This fixture has been rated for up to 40 Watt max. Three type A bulbs.
- To avoid the risk of fire, do not exceed the recommended wattage.

Pre-Assembly:

- For your safety and convenience, assembly by two persons is recommended.
- Remove all parts and hardware from box along with any plastic protective packaging.
 Do not discard any contents until after assembly is complete, to avoid accidentally discarding small parts or hardware.
- Remove metal shade ring from holder by unscrewing it.. Place glass part on holder and fix it with metal shade ring. Similarly fix other two glass shades.

Hardware Included:

- (1) Quinn beaded wall sconce metal part
- (3) glass shades
- (1) Mounting Plate
- (2) Mounting Screws
- (2) Side Screws
- (1) Grounding screw
- (1) Allen key for side screws

To install you will need:

- (1) Screwdriver
- (1) Pliers
- (1) Electrical Tape
- (2) Plastic wire connectors

To Install:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX / CIRCUIT BREAKER.

- 2. Gently pull the wiring down from the ceiling outlet box. Identify the three wires:
 - Hot wire- usually has a black covering.
 - Neutral wire- usually has a white covering.
 - Ground wire- usually has a bare copper or green covering.



