

sureSTRIP HANGING INSTRUCTIONS

MURAL INSTRUCTIONS SURESTRIP - PREPASTED

BEFORE YOU BEGIN

Carefully examine your mural before installing to ensure that it is the item you ordered, and that it is in good condition. If you find any defects during installation, not previously noticed, stop work immediately and notify the authorized retailer from whom you purchased the mural.

THE WORLD'S EASIEST WALLPAPER™



- EASY TO INSTALL
- EASY TO REMOVE

This artistically crafted mural is made of Surestrip - Preasted material, a revolutionary natural and synthetic fiber that is stronger, easier to install and easier to remove than any other wallpaper. Just roll it out. Apply to the wall (no booking necessary since Surestrip does not shrink and therefore guarantees not to create any unsightly seams). When you are ready to redecorate, simply pick the corners and pull off the wall. Surestrip comes off in seconds and in full strips. No tools needed! Guaranteed ()!*

WALL PREPARATION

To maximize the unique properties of Surestrip, surfaces should be made clean and smooth, and primed with a pre-mixed, specialty wallcovering primer, to ensure proper adhesion and future removal.

TOOLS YOU MAY NEED

- Wallpaper smoothing brush • Scissors
- Supply of clean fresh water
- Cleaning sponge or lint free white towels
- Measuring tape • Level or plumb bob
- Broad knife or trim guide • Pencil
- Snap off knife and extra blades

STARTING POINT

Your mural has been carefully rolled, with each panel numbered sequentially in the order that they are to be installed – starting on the left side of the wall and left side of the mural.

Based on the measurements of your mural, determine its location on the wall, and using a level or plumb, mark a vertical line (in pencil) where the left edge of the mural will fall. That will be your starting point for the left edge of the first panel.

If installing to a corner, draw your vertical line 17.5" from the corner and align the right edge of the first panel to this line as your starting point. By starting 17.5" from the corner instead of the full 18" width of the panel the extra half inch margin will cover imperfections in the plumb of your walls and allow you to trim your mural perfectly into the corner.

HANGING PROCEDURE:

Remove the first panel (#1) from the bolt. Re-roll single panel with paste side out and submerge in water tray filled with clean water for approximately 30 seconds to activate paste. Caution: Avoid use of a wallpaper paste with SureStrip preasted wallcoverings. It could make installation and future removal more difficult.

Remove panel from water by grabbing the end of the roll and unwinding it slowly from the water tray, making sure that all of the paste side has been moistened. For ease of handling, fold each end of the moistened panel toward the middle, paste side to paste side, being careful not to crease the folded ends.

Take the moistened panel directly to the wall and slide into place, aligning the edge with the vertical plumb line you drew earlier.

Smooth the strip into position using a damp sponge or wallpaper smoothing brush.

Trim excess at top and bottom of strip with a razor knife, changing blades frequently to ensure clean cuts. Use a metal straight edge as a guide when trimming.

Immediately clean excess paste from the surface of the mural panel and along woodwork and ceiling with CLEAN water and a CLEAN white cloth or uncolored sponge, changing water frequently. Do not allow adhesive to dry on the surface since some adhesives could adversely affect the mural over time.

Repeat this same procedure for the remaining panels, matching each subsequent panel to the previous strip. Butt seams together and match at eye level, smoothing upward and downward from there. Do not overlap.

Because SureStrip material does not expand or contract when wet, it will hold its position on the wall without shrinking back at the seams. Re-check previously installed panels making certain that all edges are smoothed firmly to the walls.

CARE AND MAINTENANCE / HELPFUL HINT

These murals are washable. Most common soils, grease and stains can be removed by washing with soap or mild detergent and water. Fresh grease stains can normally be removed by wiping off immediately with an absorbent paper towel. For best results, all marks should be removed promptly.

GUARANTEE

These murals are manufactured under stringent quality control procedures, and are inspected prior to shipment. The manufacturer warrants it to be free of defects in material and workmanship, and will replace any material found to be defective, or at its option, will refund the purchase price thereof.

(* Ask your York authorized dealer about the additional Surestrip guarantee.

French and Spanish Mural Hanging Instructions are listed above.