



Step 1 - Use the velcro around the slipcover to cover the MDF board with EVA.

Step 2 - Put the MDF board with EVA covered with slipcover into the frame.

Step 3 - Put the backing into the frame.