

OVERBALANCE

To prevent injury and property damage from unexpected tipping of furniture, we highly recommend installation of the one (1) set of overbalance protection hardware included with this product.

1. Attach the mounting bracket (I) horizontally to the top back edge of the furniture. Insert the short screws (III) through the holes in the bracket (I) and tighten securely using screwdriver.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw holes. It should be placed approximately 2" below the bracket mounted to the furniture.
3. Attach the mounting bracket (I) vertically to the wall by inserting the long screws (IV) provided through the holes in the bracket and tightening securely using screwdriver.
4. Place the furniture so the brackets (I) on the back edge are in line with the brackets (I) on the wall.
5. Lace an end of the nylon restraint strap (II) down through each bracket (I). Bring both ends together and slide the thin end of the strap through the receiving end of the strap until snug.
6. Check to make sure the strap is securely laced and locked to the brackets.

