

west elm: geometric storage unit

assembly instructions

OVER BALANCE. To prevent injury and property damage from unexpected tipping of furniture, we highly recommend installation of the two (2) sets of overbalance protection hardware included with this product.

1. Attach the two mounting brackets securely to the back edge of the furniture. Place one on each of the side panels.
2. Determine where the furniture is to be placed and mark location on the wall for the other two mounting bracket screw holes. It should be placed approximately 2" below the bracket mounted to the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic anchor into the hole and gently tap until the flange on the anchor is against the wall surface.
4. Position the bracket over the anchor and use a screw to securely attach the bracket to the wall. Repeat steps 3 and 4 for the second bracket.
5. Place the furniture so the brackets on the back edge is in line with the brackets on the wall.
6. Lace an end of the nylon restraint strap down through each bracket. Bring both ends together and slide the beaded end of the strap through the keyhole shaped slot in the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock, return the beaded end back through the keyhole.
8. Check to make sure the strap is securely laced and locked to the brackets.
9. Repeat steps 6 through 8 for the second bracket set.

