POTTERYBARN

Rope Wrapped Mini Lamp Table Assembly Instructions

Important Safety Instructions:

- This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- This fixture has been rated for up to (1) 25-watt maximum Type B standard (candelabra) incandescent light bulb (not included) or one (1) 5- watt LED light bulb (included for California Customers). To avoid the risk of fire, DO NOT EXCEED THE RECOMMENDED LAMP WATTAGE.
- Use with approved PotteryBarn Shades only, having a minimum opening diameter of 3 inches and a minimum lamp-to-shade spacing of 1-5/8 inches.
- This lamp is meant for indoor use.
- · Save these instructions.

WARNING:


- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- · Keep flammable materials away from lit bulb.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts Included:

- (1) Shade (A) with Clip (D).
- (1) Lamp Base (F)



To Assemble:

- Insert (1) 25-watt maximum Type B standard (candelabra) incandescent light bulb (not included) or one (1) 5watt LED light bulb (included for California Customers) into the Socket (C). DO NOT EXCEED THE SPECIFIED WATTAGE.
- 2. Smoothly open both end of Clip (D) and place the shade on bulb.
- 3. Plug fixture into the proper electrical outlet and test fixture.
- 4. Assembly is complete.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

Thank you for your purchase stores | catalog | www.potterybarn.com USA 1.888.779.5176