

P O T T E R Y B A R N

Pendant Bulb Kit Assembly Instructions

IMPORTANT SAFETY INSTRUCTIONS:

- These instructions are provided for your safety. It is important that they are read carefully and completely before installing fixture.
- **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.**
- We strongly recommend that a professional electrician install all direct wire fixtures.
- This fixture has been rated for up to **(1) 75-watt maximum E26 TYPE A standard bulb** (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- The lighting fixture is meant for indoor use, **SUITABLE FOR DAMP LOCATIONS..** It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- Save these instructions.

WARNING:

- **To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.**
- **Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.**
- Keep flammable materials away from lit bulb.

WARNING:

- This lighting fixture contains lead, a chemical know to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

Pre-assembly:

- For your safety and convenience, assembly by two people is recommended.
- Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts Enclosed:

- (1) Green ground screw (A)
- (1) Mounting plate (B)
- (1) Canopy (C)
- (4) Plate screw(D)
- (1) Socket (E)
- (1) Socket ring (F)
- (3) Shades (G)
 - (1)Bell metal shade
 - (1)Springfield mirror shade
 - (1)Flare metal shade
 - All of not included & sold separately
- (1) Ribbed glass Shade (included H,I,J)
 - (1) Ribbed glass (H)
 - (4) Metal screw (I)
 - (1) Glass diffuser (J)
 - not included & sold separately
- (1) Cage metal Shade (included k,L)
 - (1)Shade top (K)
 - (1)Shade bottom (L)
 - not included & sold separately

Hardware Included:

- (3) Plastic wire connectors (a)
 - include (1) extra.
- (3) Mounting screws (b)
 - include (1) extra screws.

Tools required for assembly:

- Phillips screwdriver
- Electrical tape
- Wire cutters

To Install:


1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
2. This chandelier / lantern features extra electrical cord. Carefully measure the length you wish to mount chandelier / lantern. Once you have determined the correct length, cut the cord and remove any extra links from the support chain (if applicable). Prior to cutting the cord make sure to leave enough electrical cord to properly install the chandelier / pendant.
3. Unscrew the Plate screw(D) from the Canopy (C) and take out Mounting plate (B).,
4. Gently pull wiring down from the ceiling junction box and allow it to hang. Thread the wires through the center hole on the Mounting plate (B).
5. Carefully inspect the fixture's wires. The NEUTRAL FIXTURE WIRE is marked "N". The HOT FIXTURE WIRE is marked "L". The bare copper wire is the GROUND WIRE.
6. Attach the GROUND WIRE from the fixture to the GROUND JUNCTION BOX WIRE from the outlet (usually green or bare wire). Fasten each together with a Plastic wire connector (a) and wrap the connection with electrical tape. Be sure that no wire strands are exposed. If your outlet box DOES NOT have a GROUND WIRE, insert the green ground screw (A) into the mounting plate (B) facing DOWN, and wrap the fixture's bare ground wire around the ground screw. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED!
7. Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL JUNCTION BOX WIRE. Fasten each together with a Plastic wire connector (a) and wrap the connection with electrical tape. Be sure that no wire strands are exposed.
8. Connect the HOT WIRE to the HOT JUNCTION BOX WIRE. Fasten each together with a plastic wire connector (a) and wrap the connection with electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
9. Gently tuck the wire connections neatly into the ceiling junction box.
10. Secure the mounting plate (B) to the ceiling outlet box using the enclosed Mounting screws (b), Tighten screws with a screwdriver.
11. Pull canopy (C) up over the mounting plate (B) until it is flush with the ceiling.
12. Screw back the Plate screw (D) to secure the canopy.
13. Unscrew the Socket ring (F) from the socket (E),
14. ***Attach the shade (G) to the socket (E) and screw back the shade ring (F) to secure the Shade (G) as show in the illustration below. Please refer to Fig 03. Insert **(1) 75-watt maximum E26 TYPE A standard bulb** (not included) into the Socket. **DO NOT EXCEED SPECIFIED WATTAGE.**

***Unscrew the Metal screw (I) from the Ribbed glass (H) by hand and take out the Glass diffuser (J), attach the Ribbed glass (H) to the socket (E) and screw back the shade ring (F) to secure the Shade (G), Insert **(1) 75-watt maximum E26 TYPE A standard bulb** (not included) into the Socket. **DO NOT EXCEED SPECIFIED WATTAGE.** Insert the Glass diffuser (J) into the Ribbed glass (H) , plates by first aligning the pre-drilled holes of Ribbed glass (H) with the pre-drilled holes of the Glass diffuser (J). and screw back Metal screw (I) Tighten screws by hand. as show in the illustration below. Please refer to Fig 01

*** Unscrew the Shade bottom (L) from the Shade top (K), attach the the Shade top (K) to the socket (E) and Slowly turn the Shade top (K) clockwise , until it is tight with the socket (E), screw back the shade ring (F) to secure the Shade (G) if need , Insert **(1) 75-watt maximum E26 TYPE A standard bulb** (not included) into the Socket. **DO NOT EXCEED SPECIFIED WATTAGE.** Attached the Shade bottom (L) onto the Shade top (K) and secure the shade bottom (L) , as show in the illustration below. Please refer to Fig 02
15. Restore power to junction box and text fixture.
16. Assembly is completed.

Care Instructions:

- Wipe with soft dry cloth for daily cleaning.
- Always avoid the use of harsh chemicals or abrasives as they may damage the finish.



thank you for your purchase
 Stores | catalog | [www.potterybarn](http://www.potterybarn.com)