
pottery barn kids



PRESTON ART CONSOLE

www.potterybarnkids.com

Date: 2015-Sept-07 Page 1 of 3


Important Safety Instructions:

- Please read all instructions carefully before assembling.
- For your safety, assembly by two or more adults is strongly recommended.
- · Keep instructions for future use.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:

- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.

Hardware Included:




Tools Required:

Phillips Head Screwdriver (not included)




Assembly Instruction Steps:

1. If the Art Consoles doesn't sit level, adjusts the levelers as shown below.



Multiple Art Consoles can be combined together by following the assembly instructions below:

- 2. Place the Art consoles in the desired location.
- 3. Align the Art consoles together.
- 4. Place Metal Bracket (A) over the pre-drilled holes, on the rear side of Art Console, as shown below.
- 5. Secure with 4 Short Screws (B) and tighten with a Phillips Head Screw Driver (not included).



6. NOTE: Installation of the Anti Tip Kit is REQUIRED. Please follow the separate instructions to secure the Art consoles to the wall, by using the tipping-restraint kit included.

Care Instructions:

- Dust often using a clean, soft, dry and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight.
 Re-tighten if necessary.

Thank you for your purchase Stores | catalog | www.potterybarnkids.com USA 1.800.290.8181

Date: 2015-Sept-07 Page 3 of 3