


pottery barn kids

Finley Play Table

PRE-ASSEMBLY:

- Please read all instructions before beginning assembly.
- For your safety and ease, assembly by two adults is recommended.
- Remove all parts and hardware from box and lay out on a carpeted or scratch-free work surface, as this will avoid damaging any parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists to identify and separate each of the pieces included.
- Note: Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.
- The use of power tools for assembly is not recommended. Power tools can damage hardware or split wood.




PARTS INCLUDED:

- (A). Tabletop – 1pc
- (B). Leg – 4pcs

ASSEMBLY INSTRUCTIONS:

1. Place Tabletop (A) on a soft, scratch free surface. Thread and tighten (4) Legs (B) into pre-drilled holes located under the tabletop. Turn assembled table to upright position.



CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish

Thank you for your purchase.
stores | catalog | www.potterybarnkids.com
USA 1.800.290.8181