

METAL CLOTHING RACK

Important Safety Instructions:


- Please read all instructions carefully before assembling.
- For your safety, assembly by two or more adults is strongly recommended.
- Keep instructions for future use.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:



- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.

Parts Included:


- (A) Base Side 2x
- (B) Bottom Rail 3x
- (C) Top Rail 1x
- (D) Post 2x
- (E) Caster 4x



Hardware Included:


<p>(F) Bolt</p>  <p>Dia.6 x 16mm 12x</p>	<p>(G) Bolt</p>  <p>Dia.8 x 54mm 2x</p>	<p>(H) Flat Washer</p>  <p>Dia.25 x 2mm 2x</p>
---	--	--

Tools Required (not included):




Assembly Instruction Steps:


1. Attach both base sides (A) to bottom rails (B) as shown. Insert bolts (F), tighten with 4mm Allen wrench (I).




2. Screw the Casters (E) as shown with open wrench (K).



3. Screw the post (D) into top rail (C) as shown.



4. Attach the assembly in step 3 and flat washer (H) to assembly in step 2 as shown, insert the bolt (G) from bottom, tighten up bolt with 5mm Allen wrench (J). Assembly is complete!



Care Instructions:

- Dust often using a clean, soft, dry and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight.
Re-tighten if necessary

Thank you for your purchase
Stores | catalog