

Swoop Side Table

Important Safety Instructions:


- Please read all instructions carefully before assembling.
- For your safety, assembly by two or more adults is strongly recommended.
- Keep instructions for future use.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:





- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.

Parts Included:


- (A) Top Panel 1x
- (B) Leg 4x



Hardware Included:

<p>(C) Flat Washer</p>  <p>8x</p>	<p>(D) Spring Washer</p>  <p>8x</p>	<p>(E) Bolt</p>  <p>M6 x 55mm 8x</p>	<p>(F) Allen Wrench</p>  <p>1x</p>
--	--	--	---

Attach Leg (B) to Top Panel (A) as shown, insert Bolt (E) thru Spring Washer (D) and Flat Washer (C) and tighten with Allen Wrench (F).



Care Instructions:

- Dust often using a clean, soft, dry and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight.
Re-tighten if necessary.

Thank you for your purchase
Stores | catalog