

## Rockin' Plush Speaker


This item is powered using three (3) AA (R6) batteries. Batteries are not included.

Note: Rechargeable batteries are the best battery option for the Rockin' plush. The second best option is to use alkaline batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

**Tools Needed:** Phillips screwdriver (not included)

### BATTERY INSTALLATION:

1. The battery box can be found hidden at the back or bottom of the product behind a Velcro flap. Open the Velcro flap and gently pull out the battery box to access.
2. To open the cover of battery box, loosen the screw on the battery box cover to access the battery compartment.
3. Insert three (3) "AA" batteries, taking care to match the battery direction to the polarity markings (+ and -) in the battery compartment.
4. Place the battery box cover back and fasten the screw to secure the cover in place.
5. Slide the ON-OFF switch to the "ON" position and it is ready to use.  
**Note: To prolong battery use, slide the ON-OFF switch to the "OFF" position when not in use.**
6. Place the battery box into the product and close the Velcro flap.
7. Insert the audio cable located in the front pouch of the product into the headphone jack of your media player or phone.
8. Select music and adjust the sound level using your media player or phone music player's controls.



### BATTERY SAFETY INFORMATION:

Rechargeable batteries must be removed from the products before being recharged and the rechargeable batteries should be charged by adult. Non-rechargeable batteries are not to be recharged. Remove drained batteries from the unit. Do not short-circuit the battery terminals. Batteries are to be inserted in the correct polarity. Battery must be recycled or disposed properly. To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge standard or alkaline batteries. Please dispose of batteries safely according to the battery manufacturer's instructions and state and local codes. If battery leakage occurs and comes in contact with the skin or eyes, wash immediately with plenty of water.

- Remove all batteries if product is to be stored or not used for an extended period of time.
- Remove used batteries promptly.
- **Always replace batteries as a simultaneous set.**
- **Do Not Mix Old And New Batteries. Do Not Mix Alkaline, Standard (Carbon - Zinc), Rechargeable Nickel - Cadmium or Rechargeable Nickel Metal Hydride Batteries.**

**Thank you for your purchase!**