

assembly instructions  
le fait de monter des instructions  
instrucciones de montaje

Important Safety Instructions:

- For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it-contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.
- The instruction is provided for your safety. It is important that they are read carefully and completely before assembling fixture.
- This fixture has been rated for up to 60 Watt TYPE A standard incandescent light bulb (not included) or 13-watt compact fluorescent bulb (included). To avoid the risk of fire, do not exceed the recommended wattage.
- Save this instruction.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and unplug, allowing it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on.
- Do not look directly at lit bulb. Keep flammable materials away from lit bulb.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts enclosed:


- (1) Finial (A)
- (1) Harp Top (B)
- (1) Harp (C)
- (2) Harp Caps (D)
- (1) Socket (E)
- (1) Saddle (F)
- (1) Shade (G)

To Assemble:

1. Lightly squeeze the harp (C) and Insert it into the saddle (F), lower the two harp caps (D) until they cover the two-pronged saddle (F).
2. Unscrew the finial (A) from the harp top (B). Place shade (G) over the assembled harp, making sure the harp top (B) extends through the hole at the top of the shade (G).
3. Attached the finial (A) and tighten to secure the shade (G).
4. Insert a bulb-Max 60 watt maximum TYPE A standard incandescent light bulb (not included) or 13-watt compact fluorescent bulb into the socket (E). DO NOT EXCEED SPECIFIED WATTAGE.
5. Plug fixture into the proper electrical outlet and test fixture.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.



west elm

abacus table lamp

assembly instructions  
le fait de monter des instructions  
instrucciones de montaje

west elm

abacus table lamp

assembly instructions  
le fait de monter des instructions  
instrucciones de montaje