


- Use with a type A bulb. DO NOT USE WITH A BULB EXCEEDING 60WATTS.
- Electric bulb should be centered inside the shade, making sure it does not touch the sides of the shade.
- Recommended for use with west elm lamp shades only.

**Assembly Instructions:**

1. Place the harp (A) into the socket.
2. Place the shade (B) onto the harp and screw the finial (C) onto the harp, securing the shade.
3. Screw in lightbulb.

**CARE INSTRUCTIONS.**

Hardware may loosen over time. Periodically check that all connections are tight.  
Wipe base with a soft, dry cloth. To protect the finish, avoid the use of all chemicals and household cleaners.