

VINFAST EBIKE APP

User Manual

Version: 1.8

Release date: 15.04.2024




TABLE OF CONTENTS

01. INTRODUCTION	03	4.3 Search and navigate	20
1.1 Introduction	04	4.4 In-ride mode	21
1.2 Welcome screens	05	4.5 Add/Edit stop	22
02. SIGN UP/LOGIN	06	4.6 Save route	23
2.1 Sign up	07	05. RIDE STATISTICS	24
2.2 Login	09	5.1 Ride history view	25
2.3 Forgot password	10	52 Ride details	26
03. PAIRING E-BIKE WITH MOBILE APP	11	5.3 Compare ride	27
3.2 Pairing bike	12	06. SETTINGS	28
3.3 Unpair bike	14	6.1 Bike settings layout	29
04. HOME	16	6.2 Riding mode	30
4.1 Home layout	17	07. ACCOUNT	31
4.2 Turn on your bike	18	7.1 Account layout	32








VINFAST E-BIKE APPLICATION

The VinFast e-bike application serves as a specific tool, facilitating seamless connectivity and remote control of the VinFast electric bike via a mobile device.


You can effortlessly connect to your e-bike and always remain updated on your bike's battery status, speed, and distance traveled. The app's user-friendly interface allows you to customize your ride by adjusting power levels, ensuring an optimal blend of efficiency and performance, plan a route, and discover scenic trails with turn-by-turn directions, etc

Embrace the future of e-biking with our app – the ultimate companion for those who seek a connected, customizable, and secure riding experience.

Hope you enjoy your experience with VinFast!







9:41


^(*) Some features are not currently available for every model, region or language.


^(**) Work in progress, details and illustrations may not represent the final version.




WELCOME SCREENS

After installing and opening the app for the first time, you'll see the welcome screens:


















SIGN UP



Tap Register on the screen



Choose your current region to continue*




Fill in your first name

07 VinFast confidential


^{*}You will need to select a region for the first login, and from the second login onward, your choice will be remembered.




SIGN UP (CONT)



Fill in your last name information




Fill in your email address and password, then agree with our terms to continue




Click "Confirm my account" in your email to complete registration




LOGIN




Tap **Login** on the screen



Enter your email address and password and tap Login



Give permission to location access for the app for better experiencce




ACCOUNT NOT YET ACTIVATED


In case your account is not yet activated, choose **Resend Email** and follow instructions in email to complete the registration




FORGOT PASSWORD




If you already had a VinFast account but do not remember your password to log in, choose **Forgot Password** and fill in your email



Fill in the verification code sent to your email to continue



If the verification code is correct, you can update your password




Once your password is updated, you can use your new password to log in to the app



PAIRING E-BIKE WITH MOBILE APP





PAIR YOUR BIKE



Choose **Ready to start** to start

connecting to your new bike






Once your bike is paired, you can check its basic information including VIN, model and color


STEP 3




PAIR YOUR BIKE (CONT)



Go to **Home > Settings** and choose next to your bike




Choose at the end of the screen to add another bike to your account




Choose **Ready to start** to start connecting to your new bike



UNPAIR BIKE




Go to **Settings** > **Unpair Bike** at the end of the list



Select the vehicle that you want to remove and tap


Unpair




Choose **Unpair** to continue



UNPAIR BIKE (CONT)



Enter your Password for verification



A message is shown if the bike is unpaired successfully







HOME LAYOUT

Home screen includes the following features:

1 Account

Account information

2 Search

Search by POI, POI of Category

3 Bike

Locate bike's location

4 Device

Locate mobile device's location

5 Power Button

Turn ON/OFF bike, start riding

6 Widget Extension

Quick access to some features

Map Type

Change map type view

8 Favorite Places

Quick access to favorite list

9 Pinned Routes

Quick access to favorite routes

10 Home

11 Statistics


View ride detail statistics

12 Settings

View and adjust bike settings


13 More


Account information and other app settings






TURN ON YOUR BIKE








Your bike will be ready for riding after 2 seconds




Screen turns into in-ride mode with real-time updated statistics



SEARCH AND NAVIGATE TO DESTINATION




Type, use voice to search or choose a place on the search bar suggestion to search for your destination




The app displays a list of nearby places, choose a place you want

STEP 2



You can share the location or mark it as favorite. Choose **Get Directions** to check the route




Route details will show estimate time arrival and expected battery level to the destination. Choose


Turn on and Start ride



IN RIDE




Screen turns into in-ride mode with real-time updated statistics, riding mode can also be adjusted from this screen. You can swipe down from the top of the screen to navigate to destination.




Follow the navigation on the map while check on real-time update stats. Tap to pause the ride

STEP 2



If you choose Resume, there is a countdown screen to go back to inride mode. You can also end the ride at this screen.


STEP 3




You can choose to save or delete the trip history




ADD/EDIT STOP



At the get directions screen, you can tap + to add a stop




Drag and drop to adjust the order of the destinations or choose Done when you are done





You can edit the route by tapping before start riding




SAVE ROUTE








There is a message to confirm the route is saved and the pin icon will change to white color



Quick access to the saved route list from Home by tapping



Tap and you can rename or remove route

STEP 4








RIDE HISTORY VIEW








Easily check on your ride history with month, week or day view




RIDE DETAILS




SINGLE RIDE IN A DAY

You can view the ride details directly in the Statistics screen



MULTIPLE RIDES IN A DAY

There are previews for each ride if you bike multiple rides in a day




MORE OPTIONS


You can choose in ride details to compare it with another ride, rename or remove it




COMPARE RIDE









The ride comparison screen, you can view detailed insights on distance covered, total riding time, and average speed with intuitive illustration

STEP 3








BIKE SETTINGS LAYOUT

Setting screen includes the following features:

- BatteryCurrent battery level
- Range
 Estimated range base on battery level
- Bike List


 Manage your bike(s)
- Mode5 modes: Zero, Eco, Tour, Sport, Boost
- Bike info

 General info, Battery info, Firmware version
- Unlimited ModeSpeed limit up to 45 km/h
- 7 Unpair Bike







RIDING MODE (1)



In Zero mode, the pedal assist is turned off




Energy-saving mode suitable for city commuting.
Power limit: 100~250




Allows for longer rides with moderate energy consumption. Power limit: 300~450



RIDING MODE (2)



Sport mode for faster acceleration and higher speeds.
Power limit: 500~650



Powerful mode for difficult terrain or steep hills.
Power limit: 700~1000







ACCOUNT LAYOUT

Account screen includes the following features:

- 1 Avatar
- Personal Info
- Notifications

 Turn on turn off notifications for each feature
- 4 Unit settings
 Adjust measure units
- Language
 Change the app language
- 6 Log Out
- Delete Account

