

Faceted Capiz Table Lamp (color: POOL)
Faceted Capiz Table Lamp (color: PINK)

IMPORTANT SAFETY INSTRUCTION:

For safety purpose, this lamp is equipped with a polarized plug (one blade is wider than the order). If the plug does not fit securely into your outlet, do not force it-contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way. These instructions are provide for your safety. It is important that they are read carefully and completely before using the table lamp.

This fixture has been rated for up to (1) 120Vac, 60Hz E12 9W CFL bulb (included for Lamps sold in California) OR (1) 120Vac, 60Hz E12 40W TYPE B bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.

SAVE THESE INSTRUCTIONS!

WARNING:

To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing right bulb. Do not touch bulb when fixture is turned on. Do not look directly at a lit bulb.

Keep flammable materials away from any lit bulb. To avoid risk of fire, burns, personal injury and electrical shock, this light fixture should not be played with or placed where small children can reach it.

PARTS ENCLOSED: Socket (A) Bulb (B) Lampshade (C)

TO ASSEMBLE: (when changing bulb)

- 1) Disconnect the power plug from the wall socket so that the lamp is not powered.
- 2) Reach in from the top of the shade gently grab the bulb (B) and rotate it counter-clockwise to remove from the socket (A).
- 3) Insert a new bulb (B) (1) 120Vac, 60Hz E12 9W CFL bulb or 120Vac, 60Hz E12 40W TYPE B bulb into Socket (A) and rotate the new bulb clockwise to tighten.
- 4) Reconnect the power plug of the fixture into a proper electrical outlet and test the bulb.

CARE INSTRUCTIONS:

- Clean with soft, dry cloth.
- Always avoid the use of harsh chemicals or abrasive cleaners as the may cause damage to the lamp.

Thank you for your purchase. ww

www.pbteen.com