



Parts




x5
PU Casters



x1
Hydraulic Piston




x1
Aluminium Wheelbase



x1
Pre-assembled
NeueChair™ seat


Assembly

1.




Place the wheelbase upside down and insert the 5 casters into the holes by pushing firmly.

2.



Turn the wheelbase the right side up and insert the hydraulic piston into the hole of the wheelbase.

3.



Lift the pre-assembled NeueChair™ seat and guide the socket of the seatbase onto the hydraulic piston.

Safety Information



Sit in the center of the chair, with your back to the backrest.



Do not sit at the front edge of the chair.



Do not stand on the chair.



Do not use the chair with more than one person.



Do not push the chair around when a person is sitting in it.




Do not push down on the backrest when a person is leaning back.



Do not place all your weight on the backrest only.

The recommended maximum weight load for the NeueChair™ is 110kg (240lbs). The chair should only be used normally and in a non-abusive manner. For warranty information, please visit the Warranty Section on our website.

Get to know your NeueChair™



Having trouble?


Drop us an email at info@neuechair.com, and our friendly support team will get back to you with help as soon as possible!



How to use your NeueChair™


Basic Adjustments

Learn how to use your NeueChair™ in under a minute!




ControlShift™(R): Height Adjustment

Squeeze the ControlShift™ hand lever on the **right** side to adjust the height of the chair.



ControlShift™(L): Recline Lock


Squeeze the ControlShift™ hand lever on the **left** side to lock/unlock the backrest tilt.



Armrest Adjustment

Height adjustment: Grip the stem of the armrest as shown, and pull it upwards to your desired height. To reset the height to the bottom, raise the armrest to the maximum height, then push it down.

Side adjustment: Twist the top part of the armrest to pivot it left and right.




Recline Tension Adjustment

Rotate the knob under the seat to adjust the recline tension—clockwise to increase, anti-clockwise to decrease.

Focus Mode Adjustments


The NeueChair™ also comes with a few features that allow for maximum ergonomics. We recommend implementing these changes gradually in order to give time for your body to adapt to the proper posture.



Seat Slide Adjustment


To lengthen the seat depth: While seated, press the seat slide button and push your bottom forward. This will lengthen the seat depth - good for tall people with long legs.

To shorten the seat depth: Lift yourself off the chair and press the seat slide button. The seat will slide backwards. This will shorten the seat depth, making you sit upright and pushing your back into the lumbar support.



Lumbar Support Height Adjustment

Pull up or push down on the lumbar support to adjust the height of the lumbar support.



Lumbar Support Depth Adjustment

Use your index and middle fingers to press on the buttons on both sides, and your thumb to push or pull the backrest frame to adjust how deep you want the lumbar support.