


Tools: Pencil, Philips Screwdriver,
Tape measure, Stud-Finder, Level

Hardware: TWO Anchors
TWO Screws

The hardware included with this item is meant for drywall or stud mounting only. If your walls are made from concrete, brick or plaster, please consult your local hardware store for assistance in selecting the appropriate hardware.

This mirror includes three keyholes on the back for mounting to a wall in either orientation, as illustrated below. Select only two keyholes for hanging to a wall, depending on the desired orientation. Use a tape measure to measure the distance between the two selected keyholes. This is Measurement (A).



Mounting Instructions:

- A) With the help of another person, hold the mirror level against a wall at a desired mounting location and orientation so that the rear of the mirror faces towards you. Use a pencil to mark the sides of the mirror immediately adjacent keyholes, depending on the orientation. Set the mirror aside.
- B) Connect the two marks of Step (A) using a straightedge and a pencil. Use a level to make sure that the line is level and adjust it if necessary. Use the pencil to make two marks centered along the line so that the two marks are spaced a distance equal to Measurement (A). The mounting hardware will be installed at these two marks.
- C) Unfortunately, the provided anchors cannot penetrate wood. Therefore we have to determine if either mark of Step (B) happens to align with a wood stud. Use a stud-finder to determine. If either does, use the screwdriver to secure a screw at the mark. Rotate the screw clockwise until the screw head resides about $\frac{3}{8}$ inch from the wall. Do not use the anchor here.
- D) For marks that do not align with a stud, use a Phillips screwdriver to install an anchor into the wall. To do this, position the tip of the anchor against the wall at the lower mark and then firmly push the anchor into the wall as you rotate the anchor clockwise. The anchor is designed to drive itself into the wall as it is rotated. Continue rotating the anchor until the wide end becomes even with the surface of the wall.
- E) Use the screwdriver to secure a screw into each installed anchor of Step (D). Rotate the screw clockwise until the screw head resides about $\frac{3}{8}$ inch from the wall.
- F) Reposition the mirror so that the selected keyholes are supported by the screw heads, depending on the desired orientation.

Care Instructions: To clean: wipe with a soft, dry cloth. Do not use abrasive or strong chemical household cleaners. A household glass cleaner may be used for the mirror surfaces – spray the cleaner on a clean cloth first and then use the cloth to clean the glass. Do not spray the cleaner directly onto the glass or frame surfaces.